

SUTTLE

SAS-6W In-wall Speakers

User Guide



Installation:

- Use the included template to mark and cut the mounting hole in the drywall. Be sure the hole location allows the speaker to clear the wall stud.
- We recommend wiring with AWG 16 or larger, stranded wire.
- Find the speaker wire leads and pull them through the hole and carefully connect the leads to the speaker terminal block. Pry up the red (+) and black (-) levers and insert the wire. Then snap the levers into the 'down' or closed position, making sure to capture the wire securely. Be sure to observe proper polarity when connecting the speaker wire to the terminal block and make sure both speakers are connected the same way. To simplify installation the speaker connector may be detached from the speaker for insertion of the wire, then plugged back into the header after the wire is captured.
- Install the SAS-6W in hole. Tighten the mounting screws clockwise. The clamps will rotate outward and begin to grip the drywall. Tighten until snug.
- The speaker system is now ready to be turned on.

Features:

- 1" Ultra-wide dispersion dome tweeter
- Polypropylene cone
- 1" aluminum voice coil easily copes with the heat and power of extended use
- Two-piece speaker connector simplifies installation and provides a better connection

Specifications:

- Nominal Input Power - 20 Watts
- Maximum Input Power - 60 Watts
- Sensitivity – 89dB
- Impedance – 8Ω

Limited One Year Standard Warranty:

Suttle warrants its complete product offering to be free of factory defects in material and workmanship for a period of One Year (1) from date of shipment. Suttle will replace, FOB factory, within One Year (1) from date of shipment any product returned with proof of failure due to factory defects, provided the product has not been subjected to alterations, misuse, negligence or accident.

The exchange of any factory defective Suttle product is at the option of Suttle and in no event does Suttle assume liability for any damage beyond refund of purchase price of its nonconforming goods, or repair or replacement of the same. Do not return any product without prior authorization. To obtain approval to return merchandise, address correspondence to Suttle Customer Service.

Suttle reserves the right to modify, replace or alter material design and/or specification where form, fit and/or function of the product is unaffected. In the event of such change the level of product quality will be retained or improved.

1001 East Hwy 212
Hector, MN 55342
www.suttlesoho.com

Toll Free: 1-800-852-8662
Local: 1-320-848-6711
Fax: 320-848-2361